



Highly Recommended by Elite Players To Prevent Sticky Saxophone Keys



"Key Leaves are simply a fantastic product and long overdue in our field! I use my set every day and I highly recommend them everywhere I go."

TIMOTHY McALLISTER
PRISM Quartet, University of Michigan,
Interlochen Center for the Arts



"I play in some very demanding situations and refuse to let sticky G# trip up my sound. Key Leaves keep my saxophones playing great."

RON BLAKE
SNL Band, The Juilliard School, Mingus Big Band,
Christian McBride Big Band



"I can put the Key Leaves on the sax and trust it will be ready to play when I need it. They work simply and well."

JESSICA LURIE
Soloist, Zion80,
Tiptons Sax Quartet



"I've been using Key Leaves religiously on my low Eb and C#. They're great. It fixed sticky G#, too."

STEVE KORTYKA
Lady Gaga, Tony Bennett,
Brian Newmann Orchestra



Two identical saxophones... 200 hours of play each... No swab cleaning... Eat during play... For 12 months...	Prying Keys Open by Hand				
	Stuck Palm Keys (D - F#)				
	Stuck G# Keys				
	Stuck Low C# Keys				
	Total Stuck Key Pads				
WITHOUT Key Leaves	162	247	143	83	601
KEY LEAVES	0	0	3	4	12

www.KeyLeaves.com/Proof

98% LESS STICKY ROT

© 2018 Key Leaves Inc. All rights reserved. Key Leaves and Key Leaves Logo are registered trademarks of Key Leaves Inc.



Leave keys open to dry™

What are they?

Leaf shaped props that safely open saxophone key pads so the Eb, Low C# and G# air dry clean after you play. They slide under low Eb and C# key arms without touching pad leather. Because Low C# links with G#, all three of the stickiest pads are open to dry, preventing sticky pad rot.



Sticky G#?

Leaving open Low C# also opens G# to air dry. Some early vintage horns don't work this way so we made the props detachable for use on these early vintage saxes! Check out KeyLeaves.com/Instructions

Safe for pads?

Yes. It works without touching delicate pad leather and pads are most healthy when left open. For example, look at your low C pad or the pads under the pearls. These pads rarely stick because they are left open after you play - not rotting closed on the tone hole like low Eb.

Safe for the instrument finish?

Yes. Silver, copper, bronze, lacquer, wood & more.

Does it bend keys or weaken springs?


No. The squishy silicone flexes and bends so keys don't. It's safe enough for beginning band. Sax springs are designed to stay springy for decades. Intense field testing and endorsements from world-class pros prove that Key Leaves products are safe.

What about swabbing?

We love swabbing so much it is step one in our instructions. But we know kids struggle to learn sax hygiene, so we field tested this product without cleaning for a year (yuck). Using Key Leaves props reduced sticky key malfunction by 98% even without swabbing!



Leaf shaped props fit under low Eb & C# key arms
Opening G#, Eb and C# pads to air dry clean



How-To Videos
KeyLeaves.com/Instructions



Safe on Finishes U.S.A Made Vintage or Modern

Alto, Tenor, Bari and Bass Sax - Fits All!

